

INSTRUCTIONS

IMPORTANT! PLEASE FOLLOW THESE INSTRUCTIONS:

HOLE PUNCHING: Determine the necessary hole size you wish to punch- either 1/8" or 3/16". Set how far into your project you wish to punch the hole by using the depth guide. Insert paper, chipboard, leather, thin tin, or similar material and punch.

SETTING EYELETS & EMBELLISHMENTS: Select your eyelet or metal embellishment. Determine the correct TOP and BASE combination (see chart) for the type of metal embellishment selected and rotate block to the correct position. Place eyelet or embellishment in the hole and then line up the BASE block of the tool in the hole of the snap or eyelet and compress.

WARNING: CHOKING HAZARD. CONTAINS SMALL PIECES. NOT APPROPRIATE FOR CHILDREN.

WARNING: Be sure to follow the instructions carefully for punching and setting. Do not punch material that is too thick or dense - IT MAY DAMAGE YOUR TOOL. When setting eyelets, be sure to set the eyelet in the correct direction (not upside down). The spring-loaded post should go inside the female end of the eyelet and the base of the eyelet should flare on the bottom (base) of the tool. For more detailed setting instructions refer to chart. Failure to follow instructions for usage may result in damage of this tool and will void manufacturer warranty.

NOTE: After setting, the back side of your snap or eyelet may be bent, or curled non-uniformly. This is normal. Non-uniform splitting may occur depending upon the type of metal embellishment used, the amount of pressure you apply, and how well you line up the tool with the embellishment when setting.

Cube Chart

LETTER	TOP	NUMBER	BOTTOM	SETS
A		1		3/16" Eyelet
A		2		3/16" Eyelet & Washer
B		1		Flat Embellishment
C		3		1/8" Eyelet
C		4		1/8" Eyelet & Washer
D		3		Round Embellishment

Common Settings

<p>3/16" Eyelets</p> <p>Top: A Base: 1</p>	<p>1/8" Eyelets</p> <p>Top: C Base: 3</p>
<p>Flat Embellishments</p> <p>Top: B Base: 1</p>	<p>3/16" Eyelets & Washers</p> <p>Top: A Base: 2</p>

How To Replace Cubes:



1. Open plastic cover.



2. Pull up then push cube out.



3. Push new cube in and move to center.



4. Push new cube down.



5. Close cover.



WARNING:

WHEN COMPRESSING THE CROP-A-DILE MAKE SURE THAT THE TOP OF THE EYELET IS ALIGNED WITH THE TOP OF THE TOOL AND THAT THE BASE OF THE EYELET IS ALIGNED WITH THE BASE OF THE TOOL. FAILURE TO FOLLOW INSTRUCTIONS WILL DAMAGE THE TOOL AND VOID WARRANTY.